

1

Connectors

LV-HPC Series

High Power Connectors
for industrial trucks

Crimping, Installation and
Maintenance Instructions

Manual A84-M.en



Document Revision History:

Date :	Version	Reason for change	Pages:	Name
2014-06-30	01	First edition	all	M. Heim
2015-06-16	02	W-crimping with support	15	M.Heim
		New crimping pliers CWZ-600-1	17	
		Add slider LV320/400 version	19 ff	

Contents

Important fundamental information	4
Conventions for these instructions	4
Adherence to the instructions	6
General and safety information	7
Liabilities of the OEM, operating company and/or the maintenance staff	7
Intended use	7
Ambient conditions.....	7
Misuse	7
Residual risks and safety measures	8
Electrical hazards.....	8
Mechanical hazards.....	8
Other hazards.....	9
Description	9
Label.....	9
Technical data	10
Crimping instructions	12
Stripping	12
Crimping and identification.....	13
Heat-shrink sleeve.....	13
Crimp quality	14
Transition resistances between the crimping sleeve and the cable	14
Compression.....	14
Pull-out forces as per DIN EN 61238-1	14
Crimping instructions for main contacts.....	15
Crimping pliers for main contacts	16

Crimping instructions for pilot and auxiliary contacts	17
Crimping pliers for pilot and auxiliary contacts	17
Installation instructions	18
Installation of main contacts	18
Dismantling the main contacts	24
Installing the pilot and auxiliary contacts	25
Dismantling the pilot and auxiliary contacts	26
Extraction tools for pilot and auxiliary contacts	26
Installing the air tube adapter	28
EUW - Electrolyte circulation	29
Dismantling the pilot and air tube adapters	29
Installing the handles of different models	31
Maintenance.....	31
Plugging the device and charging connectors	32
Main contacts	32
Pin and socket housings.....	36
Slider	36
Heat-shrink sleeves	38
Strain relief	38
Handle LV (snap-on, screw-in)	39
Pilot contact adapter.....	39
Pilot and auxiliary contacts (pin, socket)	39
Electrolyte circulation	40
Keying plug	40
Cables	41
Maintenance points.....	41
Ordering the spare parts	43
Bibliography	43
List of spare parts	44

Important fundamental information

Fundamental conditions

1. Device and charging connectors may be inserted or disconnected only under load-free conditions. This means that the charger must be switched off before inserting or disconnecting to ensure that current is not flowing.
2. Device and charging connectors may be used only if they have been properly installed and are intact.
3. Device and charging connectors may be inserted or disconnected only manually. Other aids that increase the actuation forces (e.g. hammers, levers and screwdrivers) are not allowed.
4. Device and charging connectors may be operated only if they have been completely inserted. Device and charging connectors that can be inserted only with increased forces must be replaced.
5. Keep the device and charging connectors clean and, if required, clean them using compressed air. Contaminations may lead to leakage currents and increased insertion forces.

Legal instructions

Without explicit approval of SCHALTBAU GmbH, the manual may not be, fully or in parts, duplicated electronically or mechanically, distributed, modified, forwarded, translated into other languages or used in any other manner.

SCHALTBAU GmbH is not liable for damages if crimping, installation and maintenance instructions are not followed or followed only partially, if original SCHALTBAU GmbH spare parts are not used or if modified parts are used.

Conventions for these instructions

The following symbols are used in this manual to indicate instructions with special significance.

DANGER



This indicates an imminent dangerous situation. If such a situation is not avoided, it may lead to death or severe injuries.

WARNING



This indicates a potentially dangerous situation. If such a situation is not avoided, it may lead to death or severe injuries.

CAUTION



This indicates a potentially dangerous situation. If such a situation is not avoided, it may lead to minor or moderate injuries.

ATTENTION

This indicates a potentially hazardous situation. If such a situation is not avoided, assemblies, system or objects in its surroundings may get damaged.



Warning against hazardous electric potential



NOTE refers to technical features and methods that facilitate work or provide information that is of special significance.



NOTE refers to technical features and methods that are executed correctly.



NOTE refers to technical features and methods that are **not** executed in the correct type and manner.

Adherence to the instructions

Device and charging connectors described here are used in industrial trucks with battery-electrical operation or similar battery-electrical applications.

DANGER



Always follow these instructions for the crimping, installation and maintenance of device and charging connectors without fail.

Only experts with adequate technical knowledge may plan and execute the mechanical and electrical installations, transport, set-up and commissioning activities and initiate maintenance and repair measures. This is applicable to the adherence of general set-up and safety regulations for working on high-voltage systems (e.g. DIN, VDE), as well as for the proper usage of approved tools and personal protective equipment. Device connectors must be protected from moisture and dust during installation, operation or storage.

In case of doubts, we recommend that you contact SCHALTBAU GmbH or the industrial truck manufacturer to get support for the installation, commissioning and all the service activities.



Figures and photos are only for the purpose of orientation. Differences between individual device and charging connectors, between the pin and the socket sides as well as different series are not shown.

General and safety information

- ▶ Crimping, installation and maintenance instructions must be read, understood and followed when carrying out all activities.

Liabilities of the OEM, operating company and/or the maintenance staff

- ▶ **Read all the safety instructions and follow them with utmost care at all times.**
- ▶ Follow all the prevailing national regulations, all safety, accident prevention and environment protection regulations as well as the recognised technological rules for safe and proper operation.
- ▶ Check all the existing protective and safety devices regularly for proper functioning.
- ▶ Only a qualified electrician or a trained person may work on the electrical devices under the guidance and supervision of an experienced qualified electrician in accordance with the electro-technical regulations.
- ▶ An expert is a person who can assess and execute essential activities and identify possible dangers based on his/her technical education, knowledge, experience and awareness about the prevalent regulations.

Intended use

Ambient conditions

Operate the device and charging connectors of the LV series only under the ambient conditions specified in the following *technical data*.


Misuse


- ▶ Repair activities other than those mentioned in this crimping, installation and maintenance manual carried out by **untrained** personnel.
- ▶ The connector of the LV series may **not** be altered or modified; else, the manufacturer's liability shall become void.
- ▶ The device and charging connectors may **not** be operated without rectifying the faults shown by the system or faults determined using any other method as well as defects such as the coding, or without the intended keying plug.
- ▶ The connector may **not** be used outside the usage conditions defined for the intended usage, such as voltage, current intensity, ambient conditions, etc.
- ▶ Inserting or disconnecting the connector using hammers and/or levers and/or screwdrivers or other aids is **not** permissible.
- ▶ Device and charging connectors may **not** be poured over with or contaminated with electrolyte liquids or other liquids.
- ▶ Operating the connector with damaged main contacts, e.g. after an emergency actuation or after inserting and disconnecting under load, is **not** permissible.
- ▶ **Never** pull or press the cables for inserting or pulling out the connectors, even when a handle is not provided. Directly hold the housing if there is no handle.

Residual risks and safety measures


Electrical hazards

Risk of electric shocks in case of direct and indirect contact with live parts.


DANGER	
	<p>Device and charging connectors have current-carrying parts. There is a risk of burns, electric shocks, short-circuit and fire.</p> <p>Ensure the following before carrying out any maintenance activities on the connector:</p> <ol style="list-style-type: none"> 1. If a connector is connected to a charger, switch OFF the charger and secure it reliably against switching on again accidentally. 2. If a connector is connected to a battery, disconnect the connection cables from the battery. <ul style="list-style-type: none"> ▶ Mark your work area clearly.

WARNING	
	<p>Keep the device and charging connectors clean and, if required, clean them using compressed air. Contaminations may lead to leakage currents and increased insertion forces.</p> <p>Device and charging connectors are normally operated with DC voltages.</p> <p>High currents may be observed in case of faults and these currents may generate light arcs when inserting and disconnecting.</p>

Mechanical hazards

CAUTION	
	<p>Ensure the following points when replacing sharp-edged or broken parts and during maintenance/repair activities:</p> <ul style="list-style-type: none"> ▶ Use suitable tools. ▶ Wear safety gloves when handling sharp-edged parts.

Other hazards

WARNING	
	<p>If the device and charging connectors carry current when inserting and disconnecting, hazardous light arcs may be generated. This may lead to premature ageing of contacts, increased insertion forces and overheating. It may also lead to a fire.</p> <p>If the battery releases hydrogen, there is a risk of explosion. Persons are also at risk in this case. Ensure adequate ventilation.</p> <p>Switch OFF the charger before inserting or disconnecting the connector.</p>

Description




Label

The label affixed on the device and charging connectors contains the following information (example):

Type designation	Series LV
Nominal operating current of main contacts	
Rated current I	160 A
Rated current II	250 A
Degree of protection when inserted	IP 23
Polarity:	+ (PLUS), - (MINUS)
Rated voltage	150 V DC

Technical data

The latest version of *technical data* can be downloaded from www.schaltbau-gmbh.com/de/Download/.

Series	Standard	LV320/400	LV160/250	LV80/120
Nominal operating current *1				
Main contacts	DIN VDE 0623-589	320 A / 400 A*1	160 A / 250 A*1	80 A / 120 A*1
Pilot contacts		20 A	20 A	20 A
Rated voltage	DIN VDE 0623-589	150 V	150 V	150 V
Code		24 / 36 / 48 / 72 / 80 / 96 V		
Nominal operating voltages	DIN VDE 0623-589	Red*1/grey: Wet-cell battery, green: Dry-cell battery, yellow: Vehicle plug		
Keying plug				
Main contacts				
Number		2	2	2
Contact diameter		10 mm	8.5 mm	6 mm
Wire gauge	DIN VDE 0623-589			+ LV RH 25/16*2+ *1
16 mm ²		---	---	●*1
25 mm ²		---	○+ LV RH 50/25*2	---
35 mm ²		○+ LV RH 50/35*2	○+ LV RH 50/35*2	---
50 mm ²		●	●*1	---
70 mm ²		●	---	---
95 mm ²		●*1	---	---
Pilot contacts				
Number		2	2	2
Contact diameter	DIN VDE 0623-589	4 mm	4 mm	2.3 mm
Wire gauge 2.5 mm ²				
Auxiliary contacts				
Number		2	2	2
Contact diameter	DIN VDE 0623-589	4 mm	4 mm	2.3 mm
Wire gauge 2.5 mm				
Air tube adapter				
Hose connection 6 mm	DIN VDE 0623-589	*5	*5	*5
Hose connection 9 to 10 mm				
Crimp connection				
Main contacts		W-crimping	W-crimping	W-crimping
Pilot contacts		W-crimping	W-crimping	W-crimping
Degree of protection	EN1175-1	IP23*3	IP23*3	IP23*3
Temperature range		-30 °C to +110 °C*4	-30 °C to +110 °C*4	-30 °C to +110 °C*4
Number of connection cycles	EN1175-1	> 5000	> 5000	> 5000
Housing				
PBT GF30 (free from PBB and PBDE) integrated interlock	UL94	●	●	●
Strain relief		●	●	●
Burning behaviour		●	●	●
V0		V0	V0	V0
Handle, variants				
Snap-on		●	●	●
Screw-in		●	●	●
Handle, colour				
Black		●	●	●
Red (emergency-stop identification)		●	●	●
Approvals				

* 1 For 400 A, 250 A and 120 A, use the corresponding red keying plug and follow the wire gauges as indicated by the DIN VDE 0623-589 standard. Please take into account the dependency of the nominal operating current on the wire gauge; see (LV320/400), (LV160/250) and (LV80/120)

* 2 Main contact with reducer: Reduction from the wire gauge of the main contact to the wire gauge of the cable

* 3 IPx3 in horizontal installation position

* 4 Please follow the current carrying capacity curves, (LV320/400), (LV160/250) and (LV80/120)

* 5 With an adapter, see below "Adapters for air tube adapter"

LV320/400

• Main contacts, aux. contacts

Main contacts Ordering code	Type	Wire gauge		Rated current	
		HPC*	Standard	HPC*	Standard
LV320 S10/95	Socket	95 mm ²	95 mm ²	400 A	320 A
LV320 P10/95	Pin	95 mm ²	95 mm ²	400 A	320 A

Aux. contacts Ordering code	Type	Wire gauge	Rated current
LV320 BCC-2.5-Ag	Socket	2.5 mm ²	20 A
LV320 SCC-2.5-Ag	Pin	2.5 mm ²	20 A

LV160/250

• Main contacts, aux. contacts

Main contacts Ordering code	Type	Wire gauge		Rated current	
		HPC*	Standard	HPC*	Standard
LV160/250 S8.5/50	Socket	50 mm ²	50 mm ²	250 A	160 A
LV160 P8.5/50	Pin	50 mm ²	50 mm ²	250 A	160 A

Aux. contacts Ordering code	Type	Wire gauge	Rated current
LV160 BCC-2.5-Ag	Socket	2.5 mm ²	20 A
LV160 SCC-2.5-Ag	Pin	2.5 mm ²	20 A

LV80/120



• Main contacts, aux. contacts

Main contacts Ordering code	Type	Wire gauge		Rated current	
		HPC*	Standard	HPC*	Standard
LV80/120 S6/25	Socket	25 mm ²	25 mm ²	120 A	80 A
LV80 P6/25	Pin	25 mm ²	25 mm ²	120 A	80 A

Aux. contacts Ordering code	Type	Wire gauge	Rated current
LV80 BCC-2.5-Ag	Socket	2.5 mm ²	20 A
LV80 SCC-2.5-Ag	Pin	2.5 mm ²	20 A

* High Power Connector, to be used with the red keying plug

Extra air tube adapters



Do you need an adapter for air tubes with greater diameters or deviating wall thickness?

Adapters are available for adapting air tubes with the following inside diameters:

- Inside diameter Ø 9 to 10 mm
- Inside diameter Ø 6 mm and wall thickness > 1.5 mm.

Adapter	Ordering code	Figure
Adapter for 6 mm air tubes with wall thickness > 1.5 mm	LV80/160/320 V-S 6/6	①
Adapter from 6 mm to 9..10 mm	LV80/160/320 V-S 6/10	②


Crimping instructions

DANGER



Always follow these instructions for crimping the cables without fail.


Stripping




	Main contacts	Cable cross-section mm ²	Dimension L mm (+1)
LV80	LV80 P6/10	10	18
	LV80 P6/25 with LV RH-25/16	16	
	LV80 P6/25	25	
	LV80 S6/25 with LV RH-25/16	16	
	LV80 S6/25	25	
LV160	LV160 P8.5/50 with LV RH-50/25	25	20
	LV160 P8.5/50 with LV RH-50/35	35	
	LV160 P8.5/50	50	
	LV160 S8.5/50 with LV RH-50/25	25	
	LV160 S8.5/50 with LV RH-50/35	35	
	LV160 S8.5/50	50	
LV320	LV320 P10/50 with LV RH-50/35	35	20
	LV320 P10/50	50	
	LV320 P10/70	70	
	LV320 P10/95	95	25
	LV320 S10/50 with LV RH-50/35	35	20
	LV320 S10/50	50	
	LV320 S10/70	70	
	LV320 S10/95	95	
		25	

	Contacts	Designation	Cable cross-section mm ²	Dimension L mm (±0.5)
LV80	Pilot and auxiliary contacts	LV80 SBC-2.50-Ag pin	2.5	7.5
		LV80 BBC-2.50-Ag socket		
LV160	Pilot contacts	SCC-2.50-Ag pin		
		BCC-2.50-Ag socket		
	Auxiliary contacts	LV160 SBC-2.50-Ag pin		
		LV160 BBC-2.50-Ag socket		
LV320	Pilot contacts	SCC-2.50-Ag pin		
		BCC-2.50-Ag socket		
	Auxiliary contacts	LV320 SCC-2.50-Ag pin		
		LV320 BCC-2.50-Ag socket		

Crimping and identification



Dimensions for crimping



Position and dimensions for the heat-shrink sleeve

CAUTION



To ensure that the slider can latch flawlessly, maintain a distance of at least 10 mm between the heat-shrink sleeve and the collar of the contact.

Heat-shrink sleeve

Schaltbau GmbH recommends the use of a flexible, flame-resistant and/or self-extinguishing heat-shrink sleeve based on polyolefin with excellent resistance to acids and alkalis.

Temperature range -40 °C to +135 °C

Minimum shrink temperature +95 °C

Test	Test procedures	Requirement
Dielectric strength	IEC 243 and/or IEC 685 P2	20 MV/m
Fire protection properties		Flame-resistant and/or self-extinguishing




Heat-shrink sleeve, shrink rate 2:1

Ø Delivery dimension, minimum D [mm]	19
Ø after complete shrinkage, maximum d [mm]	9.5
Wall thickness WT [mm]	0.8

Crimp quality


Transition resistances between the crimping sleeve and the cable

Cable cross-section mm ²	Transition resistance (μΩ) (Empirical values in new condition)
10	80-90
16	50-60
25	20-40
35	10-30
50	10-20
70	Up to 15
95	Up to 15




Measurement points for the transition resistance

Compression



Correct W-crimping is identified by **uniformly deformed individual cores**



Hexagon crimping with defective compression, **individual cores are not deformed in some cases**

Pull-out forces as per DIN EN 61238-1

Tensile stress for cable material - copper: 60 x cable cross-section

Cable cross-section mm ²	Pull-out force (N)
10	600
16	960
25	1500
35	2100
50	3000
70	4200
95	5700

Crimping instructions for main contacts

General information

DIN EN 60352-2 – Solderless electrical connections, crimped connections is binding for the crimping of main contacts.

ATTENTION

Adhere to the following points to ensure that the crimped connections are functional at all times:

1. **Do not** solder stranded wires before crimping.
2. **Do not** solder a crimped connection after crimping.

Transition resistance

In case of a proper W-crimping, the transition resistance at the crimping point in a new cable must be in the range from 10 to 90 $\mu\Omega$, depending on the cable cross-section (see the table crimping quality – transition resistances).

Usable cables

Use rubber-insulated cables (arc welding cables as per DIN VDE 0282-6), e.g. H01N2-D. Cables deviating from this must be validated by the OEM/operating company for the respective application.

Temperature range, derating curves

The temperate range of H01N2-D cables is from -40 °C to + 110 °C taking into account the current-carrying capacity curves (base curves) and the corrected current-carrying capacity curves in the continuous operation range and the derating curves (as per DIN EN 60512-5-2, test 5b). The derating curve with the correction factor $0.8 \times I_n$ (base curve) is therefore applicable for currents that are supposed to flow continuously and not intermittently, through the main contacts of the device and charging connectors at a simultaneous current load of a maximum of 20 A of pilot contacts without exceeding the upper permissible limit temperature of H01N2-D cable of + 110 °C.

Procedure for crimping the main contacts

ATTENTION

SCHALTBAU GmbH requires W-crimping of main contacts.

- ▶ Only the W-crimping with proper deformation of individual cores ensures a gas-tight connection. The deformation of crimping sleeve and individual cores result in a structure that is insulated (cold weld) by oxygen and is therefore adequately protected from internal corrosion over a long time.
- ▶ The W-crimping leads to low oxidation during operation and ensures permanent low transition resistances as the basis for low intrinsic heating of crimping points in case of high currents.
- ▶ When w-crimping the main contacts make sure that the contacts do not become bent out of shape. To this end provide some kind of support for that part of the contact extending beyond the anvil. Make sure it rests firmly on the supporting surface.

All electrical parameters specified by SCHALTBAU GmbH are based on measurements with contacts that were made using the W-crimping.

Determining the press clamp size



SCHALTBAU GmbH recommends using the **WPH 10** crimping tool in case of large quantities of hydraulic heads **WHK 8S**, **WHK 8** or **WHK 9** of Stocko or comparable devices of other manufacturers. Refer to the following table for the correct pressing clamp size.

Crimping pliers for main contacts

Stocko WPH 10 or for larger quantities

Hydraulic heads WHK 8S, WHK 8 or WHK 9



Crimping pliers: WPH10

Pressing clamp size (Stocko WPH 10, WHK 6, WHK 9) for W-crimping

Wire gauge mm ²	Reducer	Die pair with control mark	
		Crimping anvil	Crimping stamp
10	---	10	10 – 16
16	LV RH-25/16	25	25 – 35
25	---	25	25 – 35
	LV RH50/25	50	50 – 70
35	---	35	25 – 35
	LV RH50/35	50	50 -70
50	---	50	50 – 70
	LV RH70/50	70	50 – 70
50-70	---	70	50 – 70
70-95	---	95	95 – 150

ATTENTION

A maximum of one reducer is permissible per crimping.

Crimping instructions for pilot and auxiliary contacts

DIN EN 60352-2 – Solderless electrical connections, crimped connections is binding for the crimping of pilot contacts.



SCHALTBAU GmbH recommends using the **CWZ-600-1** crimping pliers or comparable devices of other manufacturers.


Pilot contacts are crimped in a pressing clamp pair for wire gauge of 2.5 mm².

1. For this purpose, insert the stripped stranded wire into the crimping sleeve until it is visible in the inspection hole.
2. Feed the contact with the inserted stranded wire up to the end stop in the crimping pliers.
3. Then press the pliers together beyond the latching point.

Crimping pliers for pilot and auxiliary contacts

CWZ-600 -1


Crimping pliers CWZ-600-1:
Pilot contacts are crimped in a pressing clamp pair for wire gauge of 2.5 mm² of LV series.



Crimping pliers: CWZ-600-1

Installation instructions

Installation of main contacts



Installation steps for main contacts

WARNING



Follow the polarity identifications for + and - cables at the pin and socket housings.

Incorrect polarity may cause a short-circuit.


ATTENTION

For the **LV80/120** series, first install the **keying plug** and then the slider.


For the **LV320/400** series, install **auxiliary contacts** with the main contacts since the auxiliary contacts are also interlocked with the slider.

1. Install socket contacts in the socket housing with the pre-mounted pilot contact adapter or air tube adapter. Install the slider (see point 3).


- Push the pin housing on the pre-mounted battery socket. Push the pin contacts with crimped cables – for the LV320/400 series, together with auxiliary contacts, provided these are used – up to the end stop in the contact chamber of the housing.





LV 320/400 correct position main and/or auxiliary contacts before installation of the slider



LV 320/400 wrong position main and/or auxiliary contacts before installation of the slider


	<p>Align both main contacts in the housing uniformly to minimise the torsion forces in the cable. In case of short cables, especially ensure that the crimping points are aligned parallel to the resting surface of the cable shoe.</p>
---	--



- The installation of the slider shall be done at room temperature 25 ° C +/- 5 ° C.**


Option 1: One-part slider LV160 S or LV320 S (
 Press the slider for fixing the main contacts until it is latched in the housing such that both latching hooks are latched simultaneously as far as possible. (In case of **LV80/120**, install the keying plug before the slider since it is fixed by the slider.)

Option 2: Two-part Slider with a lock (light grey) LV160/250 S or Slider with a lock (black) LV320/400 S
 The two-piece slider with a lock is made of a base body, “slider”, and a moving part, “lock”. The slider can be assembled only in the unlocked position. Check the correct position before assembling.




Two-piece slider: View of individual parts LV 160/250 S Slider

Two-piece slider: View of individual parts LV 320/400 S Slider



Slider with a lock in the **unlocked** condition, Recess of the lock and the crossbar of the base body are **not** located above each other (see the arrows)




Slider with a lock in the **locked** condition, Recess of the lock and the crossbar of the base body are located above each other (see the arrows)
Note: The letter "Z" is visible in the locked condition.

Coding of housing LV320/400 housings:

ATTENTION

In the LV320/400 housings install always the accompanying LV320/400 S Slider with a lock.




Correct installation of LV 160/250 S slider with a lock in LV160/250 housings



False installation of LV 160/250 S slider with a lock in LV320/400 housings



Correct installation of LV320/400 S slider with a lock in LV320/400 housings



Wrong installation of LV 160/250 S slider with a lock in LV320/400 housings

Installation of Slider with a lock: LV 160/250 and LV 320/400



Insert slider in its **unlocked** position into the housing, push with simultaneous application of force until it locks into the housing




Don't press the slider in its locked position into the housing!

Never press in the slider in center area!



Slider assembly with mounting tool



Optional, push the slider with the mounting tool.



Two-sided application of force with mounting tool.



Push the slider in its locked position with a flat-head screwdriver in the locked position by approximately 4 to 5 mm until the end stop so that the recess and the cross bar are located above each other. (See the arrows).

Slider in the locked position, Recess and the crossbar are located above each other (see the arrows)
Note: The letter "Z" is visible in the locked condition.

4. In case of the one-piece slider LV160 S or LV320 S without a lock, insert a flat-head screwdriver, which head thickness x head width between 1.0 mm x 5.5 mm to 1.2 mm x 6.5 mm, into the position shown below up to the end stop and use a slight rotary movement to check whether the slider seats firmly in the housing. The slider must be latched on both sides.
For the slider with a lock, LV160/250 S or LV320/400 S, only check whether the lock is interlocked up to the end stop.




Position of the screwdriver for checking the firm fit of the one-piece slider.

5. Slightly pull cables of contacts - also at cables of auxiliary contacts for **LV320/400 series** if required - to check whether contacts are correctly fixed.
6. Push the respective housing on the pre-mounted counter housing up to the end stop.




After installing the main contacts, we recommend mating of the connector halves before tightening strain relief screws. This ensures optimum co-axiality of main contacts and enables easy insertion and disconnection of the device and charging connectors.

7. Screw the upper and lower clamps of the strain relief such that all cables are uniformly and reliably secured against pull (see the following images). The tightening torque for screws is 1.5 Nm. Ensure that a suitable cross-recess insert is used.



Uniformly screwed strain relief




Non-uniformly screwed strain relief

Dismantling the main contacts



The slider must be removed to dismantle the main contacts - even the auxiliary contacts for the **LV320/400 series** if required. Insert a flat-head screwdriver, which head thickness x head width between 1.0 mm x 5.5 mm to 1.2 mm x 6.5 mm, in the position shown below up to the end stop and use a slight rotary movement to lift the slider slightly from its seat until it unlatches. Reuse the slider only if it is undamaged.



Position of the screwdriver for dismantling the slider.



In case of the **slider with a lock**, move the lock up to the end stop in the **unlocked** position before dismantling. If the lock is not entirely at the unlocked position, the slider may get damaged. When reusing the slider, ensure that there are 4 latching hooks (see chapter "Maintenance of sliders")

Installing the pilot and auxiliary contacts



Installation direction of pilot and auxiliary contacts



For socket contacts, pilot contact adapter is pre-mounted in socket housing.

1. Push pilot contact adapter into connector housing until it latches.
2. After it latches, press the pilot contact adapter against the installation direction to check whether the pilot contact adapter sits firmly.
3. Push pilot contacts / auxiliary contacts (with crimped cables) into the contact chambers of the pilot contact adapter and the housing (auxiliary contacts) till the end stop.
4. Slightly pull at the cables of pilot contacts / auxiliary contacts to check whether the contacts are correctly fixed.

ATTENTION

For **LV320/400 series**, install **auxiliary contacts** with the main contacts since the auxiliary contacts are also interlocked with the slider.

WARNING



The connector may not be operated **without the pilot contact adapter** or **without the air tube adapter with a spacer** in the **socket housing**.
For the installation location of the connector, ensure that battery acids do not enter the connector as a result of electrolyte circulation.

Dismantling the pilot and auxiliary contacts

Extraction tools for pilot and auxiliary contacts

You can refer to the following table for extraction tools to be used depending on contact type and the series.

Series	Contacts		Tool
LV80	Pilot contacts	LV80 BBC-2.5-Ag	Extraction tool LV80 AWZ-B
		LV80 SBC-2.5-Ag	
	Auxiliary contacts	LV80 BBC-2.5-Ag	
		LV80 SBC-2.5-Ag	
LV160	Pilot contacts	BCC-2.5-Ag	Extraction tool AWZ-C/H
		SCC-2.5-Ag	
	Auxiliary contacts	LV160 BBC-2.5-Ag	Extraction tool LV160 AWZ-B
		LV160 SBC-2.5-Ag	
LV320	Pilot contacts	BCC-2.5-Ag	Extraction tool AWZ-C/H
		SCC-2.5-Ag	
	Auxiliary contacts	LV320 BCC-2.5-Ag	Auxiliary contacts are interlocked with the slider
		LV320 SCC-2.5-Ag	




Extraction tool AWZ-C/H
for pilot contacts of the
LV160/250 and LV320/400 series



Extraction tool LV160 AWZ-B
for aux. contacts of the LV160/250 series



Extraction tool LV80 AWZ-B
for both pilot and aux. contacts
of the LV80/120 series




Dismantling direction of pilot and auxiliary contacts

Extraction tools are used for dismantling the pilot and auxiliary contacts.

1. Insert the extraction tool through the contacts up to the end stop. This will unlock the clip for fixing the contact.
2. In case of extraction tools LV80 AWZ-B and LV160 AWZ-B, use a tappet to press the contacts out from the contact chambers. In case of extraction tool AWZ-C/H, use a spring-loaded tappet for pressing the contacts out.
3. Dismantle the contacts of the cable completely from the housing by pulling them out slightly.

Installing the air tube adapter



CAUTION



When using the electrolyte circulation with the air tube adapter, pin and socket housings must be equipped with the air tube adapter. Only then is it ensured that the electrolyte fluid does not reach the connector and reduce the service life of contacts.

Pin and socket housing must belong to the same series. Air tube interfaces of old **LB series** are **not** compatible with the air tube interfaces of the **LV series**.





The air tube adapter and the spacer are always enclosed with the socket housing.

1. Push the air tube (inner \varnothing 6 mm), wall thickness \leq 1.5 mm, Shore hardness 73 on the air tube adapter to the maximum possible extent. Use the matching adapter to fix the tubes with larger inner diameters or a larger wall thickness.
2. Push the air tube adapter until it latches in the housing.
3. Then press the air tube adapter against the installation direction to check whether the air tube adapter sits firmly.
4. Insert the spacer in the socket housing up to the end stop.

The connecting piece is an adapter for fixing the air tubes with an inner diameter of:

- \varnothing 9 to 10 mm
- \varnothing 6 mm and a wall thickness $>$ 1.5 mm

 <p>Fig. 1</p>	 <p>Fig. 2</p>
<p>LV80/160/320 V-S 6/6 Adapter for 6 mm air tubes with wall thickness $>$ 1.5 mm</p>	<p>LV80/160/320 V-S 6/10 Adapter from 6 mm to 10 mm</p>


EUW - Electrolyte circulation

When charging the battery, dust-free air is fed to every cell via a blowpipe in cells. The electrolyte is swirled due to the air blown in the lower area of cells and the rising air bubbles. Uniform values of electrolyte densities are ensured along the entire length of electrodes shortly after starting the charging process.

An electrical driven air pump generates the necessary compressed air. For a secured connection, both the pin and socket housings must be equipped with the air tube adapter and the socket housing must be additionally equipped with the spacer.

The electrolyte circulation is advantageous since it ensures homogeneous temperature distribution and low temperature rise during the charging process and thereby a longer service life and shorter charging time of the battery.


Dismantling the pilot and air tube adapters



Dismantling direction of pilot and air tube adapters

Slightly lift (approximately 1.5 mm) the strap using a flat-head screwdriver (with head thickness x head width between 1.0 mm x 5.5 mm to 1.2 mm x 6.0 mm) and press the adapter backward.

Installing the keying plug



Keying plug for dry-cell battery / charging station (green)
Keying plug for wet-cell battery / charging station (grey)
Keying plug for the vehicle plug (yellow)
Keying plug for wet-cell battery / charging station (red), high current capacity (rated current II as per DIN EN 0623-589)

1. Push the keying plug for the voltage coding (corresponding to the nominal voltage of the battery) into the pin or socket housing from the front side until it latches.
2. Check the specified voltage in the inspection window of the pin or socket housing.

CAUTION






- ▶ **When keying plugs are used for the voltage coding, the charging and vehicle plug as well as the battery socket must have the same voltage coding.**
- ▶ When using the connector **without** a keying plug, the operating company must ensure the measures for the correct usage.




For the **LV80/120** series, first install the **keying plug** and then the slider.

Installing the handles of different models

		
LV to H1 handle (black) LV to H2 handle (red) Snap-on	LV to H1-SCH handle (black) LV to H2-SCH handle (red) Screwable	LV160/320 H3 handle (black) LV160/320 H4 handle (red) Snap-on


Handles (images on the left and right sides) are **snap-on**. Latch the handle in the provided fixing holes. The **snap-on** handle without screws may slip from the housing after a forced impact on the connector, e.g. due to falling. The handle must then be latched again into fixing holes. In case of LV160/250 and LV320/400, the handle can also be fixed using two screws. The tightening torque for screws is 0.5 Nm.

Alternatively, *screwable* handles (top-centre image) are also available. The tightening torque for screws is 2.0 Nm.

	Ensure that a suitable cross-recess insert is used.
---	---

Maintenance

Information regarding the expertise that is absolutely essential for maintenance is given in section *Misuse*. Before starting any work on the device and charging connectors, always ensure that these are deenergised. In addition to the primary current circuits, pay attention to the pilot and auxiliary current circuits.

WARNING	
	<p>After improper handling and additionally at least after every 1000 operating hours, all device and charging connector components and their interface components must be subjected to maintenance and checked for defects during visual inspections and, if required, the parts must be replaced immediately.</p> <p>Also check the opposite side for the damage (substitute batteries and charging devices).</p> <p>Keep the device and charging connectors clean and, if required, clean them using compressed air. Contaminations may lead to leakage currents and increased insertion forces.</p>

WARNING



Before starting work on the device and charging connectors, always adhere to the following safety rules:

- ▶ **Switch off** and secure against **restarting**
- ▶ Disconnect the battery cables
- ▶ Ensure that the parts are **deenergised** (charging device, battery)
- ▶ **Enclose** or **cover** the neighbouring live parts such as pilot and auxiliary contacts.
- ▶ Pay attention to the electrical **polarity** at the connection points of charging devices and charging cables. Mix-ups may lead to damage.




Document the maintenance activities.

Plugging the device and charging connectors

In order to ensure a safe function of the current transmission and the electrolyte circulation (density) of the device and charging connectors, plug the device and charging connector completely manually. It is considered to be completely plugged in when the gap between the collar of the pin housing and the socket housing is a **maximum of 2 mm**.

If you cannot plug the device and charging connector completely, replace the entire unit (pin and socket) immediately. It does not suffice to replace only the evidently damaged connector halve.



Permissible gap between the charging connector halves

Main contacts

Although a load disconnection is permissible as an emergency shutdown as per standard EN 1175-1 under exceptional conditions or in case of hazards, it may cause serious damage.

WARNING



If the device and charging connectors carry current when inserting and disconnecting, hazardous light arcs may be generated. This may lead to premature ageing of contacts, increased insertion forces and overheating. It may also lead to a fire.

If the battery releases hydrogen, there is a risk of explosion. Persons are also at risk in this case.

Ensure adequate ventilation.

Switch OFF the charger before inserting or disconnecting the connector.

Depending on the plugging frequency under emergency shutdown conditions or overload, the material is deposited on or removed from the contacts. Material is deposited in the contact zone. The transition resistance increases constantly and this is associated with undue heating of the device and charging connectors as well as the connected cable.

There is a risk of fire.

It may lead to increased insertion forces or complete plugging may not be possible.

CAUTION




Check the following points at the latest after every improper handling, every plugging and disconnection under load, every emergency shutdown as well as at least after every 1000 operating hours:

1. Plug and/or disconnect the device and charging connectors manually with higher force application.
2. Do not plug both connector halves completely using your hands (see the gap between the collar of the pin housing and the socket housing).
3. Check whether the unit is heated $> 65K$ during operation with respect to the ambient temperature of the housing or cables.
4. Check whether material deposit and/or removal, contamination or discolouration due to dirt, wear and mediums such as acids can be detected during a visual inspection.
5. Move or displace the main contacts by pulling the cables slightly.
6. Check whether the position of the pin and socket contacts in the housing deviates with respect to the drawing. (See the drawing "Position of socket contacts, keying plug" below).


Immediately replace the device and charging connectors that show one of the aforementioned indications.



Use a copper contact grease to lubricate the main contacts after every 1000 plugging cycles and/or every 1000 operating hours.



Right contact with material deposit or removal on the pin contact




Left pin contact contaminated due to the effect of acid, keying plug missing




Socket contact with material deposit or removal



Socket contact contaminated due to the effect of acid



Position of pin contacts, keying plug



Position of socket contacts, keying plug

Series	L1 [mm], ± 0.8	L2 [mm], 0/+1.5	L3 [mm], ± 1.55	L4 [mm], ± 2.2	L5 [mm], ± 1
LV80/120	32	2	1.5	26.5	1.5
LV160/250	38		4	40	3
LV320/400	41		10	48.9	

Pin and socket housings

Improper handling of device and charging connectors, e.g. due to forced impact on the floor, may damage the pin and socket housings, especially in the area of strain relief.

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

If the pin and socket housings show **broken points, visible cracks or deformations, contamination or discolouration due to dirt, wear and mediums such as acids** during the visual inspection, replace the **defective components immediately**.

Slider

The slider is used to hold the main contacts and ensures that users cannot touch the contacts during operation.

Improper handling of device and charging connectors, e.g. due to forced impact on the floor, may lead to broken points, visible cracks and deformations or falling of the slider or change the position of the slider.

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

1. Whether the slider is in the device and charging connectors.
2. Whether the **one-piece slider** (without a lock) fits firmly in the device and charging connectors. Check the fixing of the slider by slightly lifting at the slider using a flat-head screwdriver with (head thickness x head width between 1.0 mm x 5.5 mm to 1.2 mm x 6.5 mm) (see images 4 and 5). The slider must be latched on both sides.

Optional

For the **slider with a lock**, check whether the lock is still at the interlocked position. If required, interlock the lock again.

3. If the slider shows **broken points, visible cracks or deformations (images 7 and 8), contamination or discolouration due to dirt, wear and mediums such as acids** during the visual inspection, replace the **defective components immediately**.




Image 1: Slider is in the connector. OK.




Image 2: Slider **is not** in the connector. The charging connector may **not** be used.




Image 3: Slider in the locked position. OK. Slider is mounted parallel to the housing.




Image 4: Slider is not parallel to the housing and hence is **not** in the correct position. Left side of the slider is **not** latched.




Image 5: Check the fixing of the slider by slightly lifting at the slider using a flat-head screwdriver. Slider must interlock on both sides.



Image 6: Slider with a lock in the **locked** condition, Recess and the crossbar are located above each other (see the arrows)




Image 7: all latching hooks (2 per half) are OK. Only one half is shown here



Image 8: two latching hooks are broken. Slider is not OK if one of the four latching hooks is missing or broken bzw. die Anlagefläche beschädigt ist.



LV 320/400 S Schieber mit vollständigen Rasthaken



LV 320/400 S Schieber mit beschädigten Rasthaken



Replace the slider if one of the four latching hooks is missing or broken.

Heat-shrink sleeves

Check whether the existing heat-shrink sleeves are fixed as described in section "Crimping and identification". If required, replace the deviating heat-shrink sleeves.

Strain relief

The strain relief is made of two clamps and two screws, and has the function of protecting the connector from mechanical stresses.

Clamp, screws for the clamp

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

1. If the clamps show **broken points, visible cracks or deformations, contamination or discolouration due to dirt, wear and mediums such as acids** during the visual inspection, replace the **defective components immediately**.
2. Tighten the screws of the strain relief with a tightening torque of 1.5 Nm.

Handle LV (snap-on, screw-in)

Improper handling of device and charging connectors, e.g. due to forced impact on the floor, may lead to broken points, visible cracks and deformations in the handle.

After every instance of improper handling as well as at least after every 1000 operating hours, check the handle for defects during visual inspections and, if required, replace it immediately.



Never pull or press the cables for inserting or pulling out the connectors even if a handle is not provided. If the handle is missing, directly hold the housing of the connector.

Pilot contact adapter and air tube adapter

WARNING



Check whether **socket housing includes pilot contact adapter or air tube adapter and spacer**.

The connector may be operated only if **socket housing includes pilot contact adapter or air tube adapter and spacer**.

Pilot and auxiliary contacts (pin, socket)

Check whether the pilot or auxiliary contact is latched by slightly pulling at the cables.

Electrolyte circulation

Escaping mediums such as acids (condensate of the battery electrolyte fluid) may affect the current transmission and the insertion and disconnection forces of the charging connector severely and lead to severe heating and sometimes even short circuits.

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

Air tube adapter and spacer (socket housing)

Air tube adapter (ping housing)

Adapter (air tube adapter)

1. If the aforementioned parts show **damaged sealing outline, broken points, visible cracks or deformations, contamination or discolouration due to dirt, wear and mediums such as acids** during the visual inspection, replace the **defective components immediately**.
2. Check whether the connecting tube has the correct quality and dimensions for a safe and leak-tight connection and whether the adapter has been used for the intended purpose.

Keying plug

If the keying plug is not available or if it is broken, it may lead to incorrect plugging and incorrect voltage/current pairing.

WARNING



When using the connector **without** a keying plug, the operating company must ensure the measures for the correct usage.

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

1. If the keying plugs show **damage in the plug area, broken points, visible cracks or deformations, contamination or discolouration due to dirt, wear and mediums/liquids such as acids** during the visual inspection, replace the **defective components immediately**.
2. Check the position and the firm fitting of the keying plug.
3. Check whether the charging and vehicle plugs as well as the battery socket have the **correct** voltage coding. Replace the incorrect keying plugs **immediately**.

Cables

CAUTION



Check the following points after every instance of improper handling and at least after every 1000 operating hours:

If cables show **damage or detachment of cable insulation and/or burnt cable insulation** during visual inspections, replace **defective components immediately**.

Maintenance points



These checklists do not replace the obligation of reading and following the crimping, installation and maintenance instructions. They have been prepared only as an aid for the safe operation and use of industrial trucks as far as device and charging connectors are concerned.

Checklist for the users of industrial trucks

Tests to be conducted	Criterion	Daily before commissioning	After an incident ^{1,2}	Completed
1.) Check whether the device and charging connectors can be completely plugged manually.	Gap of a maximum of 2 mm	Yes	Yes ^{1,2}	<input type="checkbox"/>
2.) Check whether the main contacts show material deposit and/or removal, contamination or discolouration due to dirt, wear and mediums such as acids during a visual inspection.	Changes not visible	Yes	Yes ¹	<input type="checkbox"/>
3.) Check the latching and the position of main contacts and keying plugs.	Adhere to the dimensions specified in the drawing	Yes	Yes ^{1,2}	<input type="checkbox"/>
4.) Check whether the pin and socket housings, slider, clamps, handles, pilot adapter, air tube adapter, adapters and keying plugs show broken points, visible cracks and deformation, contamination or discolouration due to dirt, wear and mediums such as acids during a visual inspection.	Defects not visible, Handle, pilot or air tube adapter latched	Yes	Yes ²	<input type="checkbox"/>
5.) Check whether the slider exists and whether it latches. Optional: in case of a slider with a lock, check the position of the lock of the sliding part.	Latched on both sides, optional lock interlocked	Yes	Yes ²	<input type="checkbox"/>
6.) If the electrolyte circulation is available, check the air tube adapter and spacer (socket housing), air tube adapter (pin housing), adapter (air tube adapter) for damage to the sealing line, broken points, visible cracks and deformations, contamination or discolouration due to dirt, wear or mediums/liquids such as acids.	Defects not visible	Yes	Yes ²	<input type="checkbox"/>
7.) Check the insulation of cables (cable sheath) for damage, burnt cracks and detachments during a visual inspection.	Defects not visible	Yes	Yes ^{1,2}	<input type="checkbox"/>

¹ After an emergency shutdown or plugging and disconnecting under load.

² After improper handling, e.g. forced impact.

Checklist for the service personnel of industrial trucks

Tests to be conducted	Criterion	Service personnel: After incident	Service personnel: After at least 1000 operating hours	Completed
1.) Check whether the device and charging connectors can be completely plugged manually.	Gap of a maximum of 2 mm	Yes ^{1,2}	Yes	<input type="checkbox"/>
2.) Check heating during operation. The temperature of the housing and cables may not increase more than 65 K with respect to the ambient temperature.	Heating of the housing and cables ≤ 65 K	Yes ^{1,2}	Yes	<input type="checkbox"/>
3.) Check whether the main contacts show material deposit and/or removal, contamination or discolouration due to dirt, wear and mediums such as acids during a visual inspection.	Changes not visible	Yes ¹	Yes	<input type="checkbox"/>
4.) Lubricate the main contacts with the copper contact grease.	After every 1000 plugging cycles or every 1000 operating hours	No	Yes	<input type="checkbox"/>
5.) Check the latching and the position of main contacts and keying plugs.	Adhere to the dimensions specified in the drawing	Yes ^{1,2}	Yes	<input type="checkbox"/>
6.) Check whether the pin and socket housings, slider, clamps, handles, pilot adapter, air tube adapter, adapters and keying plugs show broken points, visible cracks and deformation, contamination or discolouration due to dirt, wear and mediums such as acids during a visual inspection.	Defects not visible, Handle, pilot or air tube adapter latched	Yes ^{1,2}	Yes	<input type="checkbox"/>
7.) Check whether the slider exists and whether it latches. Optional: in case of a slider with a lock , check the position of the lock.	Latched on both sides, optional lock interlocked	Yes ²	Yes	<input type="checkbox"/>
8.) If heat-shrink sleeves are provided, check whether their condition is OK.	Adhere to the dimensions specified in the drawing	Yes	Yes	<input type="checkbox"/>
9.) Check whether the pilot contact or air tube adapter and spacer exist in the socket housing.	Presence	Yes	Yes	<input type="checkbox"/>
10.) If the electrolyte circulation is available, check the air tube adapter and spacer (socket housing), air tube adapter (pin housing), adapter (air tube adapter) for damage to the sealing line, broken points, visible cracks and deformations, contamination or discolouration due to dirt, wear or mediums/liquids such as acids. Check the connecting tube for the correct quality and dimensions for a safe and leak-tight connection. If the adapter is provided, check it for the leak-tightness at connections.	Defects not visible	Yes ²	Yes	<input type="checkbox"/>
11.) Check the insulation of cables (cable sheath) for damage, burnt cracks and detachments during a visual inspection.	Defects not visible	Yes ¹	Yes	<input type="checkbox"/>

¹ After an emergency shutdown or plugging and disconnecting under load.

² After improper handling, e.g. forced impact.

Ordering the spare parts

ATTENTION

Use only the designated spare parts from device and charging connector series.



SCHALTBAU GmbH is not liable for damages if crimping, installation and maintenance instructions are not followed or followed only partially or original SCHALTBAU GmbH spare parts are not used or if modified parts are used or connector halves from different series are combined when using the electrolyte circulation.

Air tube interfaces of connector halves of old **LB series** are **not** compatible with the air tube interfaces of connector halves of the **LV series**.

Bibliography

DIN EN 1175-1; VDE 0117-1 / auth. DKE // Sicherheit von Flurförderzeugen - Elektrische Anforderungen - Teil 1: Allgemeine Anforderungen für Flurförderzeuge mit batterieelektrischem Antrieb. - [s.l.] : Beuth, 2011-06.

DIN EN 60352-2 / auth. DKE // Teil 2: Crimpverbindungen - Allgemeine Anforderungen, Prüfverfahren und Anwendungshinweise . - [s.l.] : Beuth, 2006-11.

DIN EN 60512-5-2 / auth. DKE // Steckverbinder für elektronische Einrichtungen - Mess- und Prüfverfahren - Teil 5-2: Prüfungen der Strombelastbarkeit; Prüfung 5b: Strombelastbarkeit (Derating-Kurve). - [s.l.] : Beuth, 2002-01.

DIN EN 61238-1 / auth. DKE // Pressverbinder und Schraubverbinder für Starkstromkabel für Nennspannungen bis einschließlich 36 kV (Um = 42 kV) - Teil 1: Prüfverfahren und Anforderungen. - [s.l.] : Beuth, 2004-03.


DIN VDE 0282-6 / auth. DKE // Starkstromleitungen mit vernetzter Isolierhülle für Nennspannungen bis 450/750 V - Teil 6: Lichtbogenschweißleitungen. - [s.l.] : Beuth, Februar 2005.

DIN VDE 0623-589 / auth. DKE im DIN und VDE // Geräte-Steckvorrichtungen für Elektro-Flurförderzeuge, Bauformen 80, 160, 320, 640 / 150 V - Teil 589: Anschlussmaße, Werkstoff, Kennzeichnung. - [s.l.] : Beuth, Juni 2011.

VdS 2259 / auth. VdS-Schadensverhütung GmbH // VdS-Richtlinie zur Schadenverhütung 2259 „Batterieladeanlagen für Elektrofahrzeuge“. - Köln : VdS-Schadensverhütung GmbH, 2010-12.

List of spare parts

The latest version of spare parts can be downloaded from www.schaltbau-gmbh.com/de/Download/.



Pos.	Designation	Ordering code			Remark	
		LV320/400	LV160/250	LV80/120		
1a	Pin housing	LV320/400 G-P	LV160/250 G-P	LV80/120 G-P	Housing for pin contacts Socket housing with Pos. 10a pre-mounted Socket housing with Pos. 15a enclosed	
1b	Socket housing	LV320/400 G-SP LV320/400 G-SL	LV160/250 G-SP LV160/250 G-SL	LV80/120 G-SP LV80/120 G-SL		
2	Slider	LV320/400 S	LV160/250 S	LV80 S	Interlocked main contacts (for LV320, even auxiliary contacts)	
3	Clamp	LV320 D	LV160 D	LV 80 D	2x strain relief	
4	Screw for clamp	SC 3.5x19 SC 3.5x25	SC 3.5x19 ---	SC 3.5x16 ---	2x self-tapping screws for strain relief: Wire gauge maximum 50 mm ² Wire gauge 75/90 mm ²	
5	Keying plug	Red Red Grey Green Yellow	LV250/400 NrS LV250/400 NrP LV160/320 Ngr LV160/320 Tgn LV160/320 Uge	LV120 NrS LV120 NrP LV80 Ngr LV80 Tgn LV80 Uge	For battery socket, high current, wet For charging station, high current, wet For battery socket/charging, wet For battery socket/charging, dry For vehicle plug	
6	Main contact	Socket 95 mm ² Socket 70 mm ² Socket 50 mm ² Socket 25 mm ²	LV320 S10/95 LV320 S10/70 LV320 S10/50 ---	---	2x main contacts for battery socket	
7	Main contact	Pin 95 mm ² Pin 70 mm ² Pin 50 mm ² Pin 25 mm ²	LV320 P10/95 LV320 P10/70 LV320 P10/50 ---	LV160 P8.5/50 ---	2x main contacts for charging station/vehicle plug	
---	Reducer	Reducer 70/50 Reducer 50/35 Reducer 50/25 Reducer 25/16	LV RH70/50 LV RH50/35 ---	---	from 70 mm ² to 50 mm ² from 50 mm ² to 35 mm ² from 50 mm ² to 25 mm ² from 25 mm ² to 16 mm ²	
8	Auxiliary contacts	Socket 2.5 mm ²	LV320 BCC-2.5-Ag	LV160 BBC-2.5-Ag	LV80 BBC-2.5-Ag	2x auxiliary contacts for battery socket 2x auxiliary contacts for charging station/vehicle plug
9		Pin 2.5 mm ²	LV320 SCC-2.5-Ag	LV160 SBC-2.5-Ag	LV80 SBC-2.5-Ag	
10a	Pilot contact adapter	Socket housing	LV160/320 PA-S	LV80 PA-S	Adapter for pilot contacts, sockets Adapter for pilot contacts, pins	
10b		Pin housing	LV160/320 PA-P	LV80 PA-P		
11	Pilot contacts	Socket 2.5 mm ²	BCC-2.5-Ag	LV80 P-S/S	2x pilot contacts for battery socket 2x pilot contacts for charging station/vehicle plug	
12		Pin 2.5 mm ²	SCC-2.5-Ag	LV80 P-P/S		
13	Pilot contact set	Adapter + socket contacts	LV160/320 P-S/S	LV80 P-S/S	Set, consisting of positions 10a, 11 Set, consisting of positions 10b, 12	
14		Adapter + pin contacts	LV160/320 P-P/S	LV80 P-P/S		
15a	Air tube adapter	Socket housing	LV160/320 LV-S	LV80 LV-S	For tube with inner Ø 6 mm Fuse of the air tube adapter (Pos. 15a) in socket housing (Pos. 1b) For tube with inner Ø 6 mm ---	
15b	Spacer	Socket housing	LV160/320 DS-L	LV80 DS-L		
15c	Air tube adapter	Pin housing	LV160/320 LV-P	LV80 LV-P		
---	Adapter	Air tube adapter	LV80/160/320 V-S 6/6 LV80/160/320 V-S 6/10		for tube diameter 6 mm For tube diameter 9 to 10 mm	
16	Handle	Black, snap-on ed, snap-on; black, screwable Red, screwable	LV160/320 H3 LV160/320 H4 LV160/320 H1/S LV160/320 H2/S	LV80 H1 LV80 H2 LV80 H1/S LV80 H2/S	Snap-on on socket / Pin housing Screw-in on socket / Pin housing, including screws	

Notes

Schaltbau GmbH

For detailed information on our products and services visit our website – or give us a call!

Schaltbau GmbH
Hollerithstrasse 5
81829 Munich
Germany



Phone +49 89 9 30 05-0
Fax +49 89 9 30 05-350
Internet www.schaltbau-gmbh.com
e-Mail contact@schaltbau.de

with compliments:



Schaltbau GmbH manufactures in compliance with RoHS.



The production facilities of Schaltbau GmbH have been IRIS certified since 2008.



Certified to DIN EN ISO 14001 since 2002. For the most recent certificate visit our website.



Certified to DIN EN ISO 9001 since 1994. For the most recent certificate visit our website.

Electrical Components and Systems for Railway Engineering and Industrial Applications

Connectors

- Connectors manufactured to industry standards
- Connectors to suit the special requirements of communications engineering (MIL connectors)
- Charging connectors for battery-powered machines and systems
- Connectors for railway engineering, including UIC connectors
- Special connectors to suit customer requirements

Snap-action switches

- Snap-action switches with positive opening operation
- Snap-action switches with self-cleaning contacts
- Enabling switches
- Special switches to suit customer requirements

Contactors

- Single and multi-pole DC contactors
- High-voltage AC/DC contactors
- Contactors for battery powered vehicles and power supplies
- Contactors for railway applications
- Terminal bolts and fuse holders
- DC emergency disconnect switches
- Special contactors to suit customer requirements

Electrics for rolling stock

- Equipment for driver's cab
- Equipment for passenger use
- High-voltage switchgear
- High-voltage heaters
- High-voltage roof equipment
- Equipment for electric brakes
- Design and engineering of train electrics to customer requirements