

New order code C137 to C165

C137 C/ 24EV-R1 001

C137: Type _____

Version: _____

- B = NO without blow-out
- C = NO with blow-out
- D = NO with blow-out, strong spring
- F = NO without blow-out,
higher insulation
- G = CO without blow-out
- H = CO with blow-out
- I = CO with blow-out,
strong spring

Coil voltage _____

Tolerance: _____

- E = +25%/-30%
- R = 0%/-30%
- B = Bistabil, +25%/-30%

Back voltage suppression: _____

- T = Transzorb Diode
- V = Varistor
- X = none

Type & number of aux. contacts _____

- R = S840 b 20
- S = S840 b 10/20
- U = S870 W1D1 a 012
- J = S870 W1D4 a 063

Special versions _____

C137	Beschreibung	Description	Alter Schlüssel
1-1618-127047	C137 H/ 48RV	Schütz W	Contacto CO S137H2/48V
1-1618-188020	C137 H/ 24RD 001	Schütz W	Contacto CO S137H2D/24V-FTS
1-1618-188031	C137 H/ 48RD 001	Schütz W	Contacto CO S137H2D/48V-FTS
1-1618-200562	C137 C/ 60EX	Schütz S	Contacto NO S137C3/60V
1-1618-262151	C137 H/ 24EV	Schütz W	Contacto CO S137H1/ 24V
1-1618-262208	C137 C/ 12EV	Schütz S	Contacto NO S137C1/ 12V
1-1618-262355	C137 H/110EV	Schütz W	Contacto CO S137H1/110V
1-1618-262571	C137 C/ 24RX 002	Schütz S	Contacto NO S137C/24V-ST
1-1618-262582	C137 C/ 48RX 002	Schütz S	Contacto NO S137C/48V-ST
1-1618-262593	C137 C/ 80RX 002	Schütz S	Contacto NO S137C/80V-ST
1-1618-262606	C137 H/ 24RX 002	Schütz W	Contacto CO S137H/24V-ST
1-1618-263187	C137 C/110EV	Schütz S	Contacto NO S137C1/110V
1-1618-263392	C137 C/ 48EX	Schütz S	Contacto NO S137C3/ 48V
1-1618-314241	C137 C/ 72EV	Schütz S	Contacto NO S137C1/72V
1-1618-315799	C137 H/ 24EX	Schütz W	Contacto CO S137H3/24V
1-1618-325149	C137 H/ 36EV	Schütz W	Contacto CO S137H1/36V
1-1618-350941	C137 C/ 48EV	Schütz S	Contacto NO S137C1/48V
1-1618-359062	C137 C/ 72RX	Schütz S	Contacto NO S137C/ 72V
1-1618-584906	C137 H/ 24RX	Schütz W	Contacto CO S137H/ 24V
1-1618-584928	C137 C/ 24RX	Schütz S	Contacto NO S137C/ 24V
1-1618-585318	C137 H/ 80RX	Schütz W	Contacto CO S137H/ 80V
1-1618-585330	C137 C/ 80RX	Schütz S	Contacto NO S137C/ 80V
1-1618-594196	C137 H/ 48RX	Schütz W	Contacto CO S137H/ 48V
1-1618-594221	C137 C/ 48RX	Schütz S	Contacto NO S137C/ 48V
1-1618-594254	C137 H/ 12RX	Schütz W	Contacto CO S137H/ 12V
1-1618-594287	C137 C/ 12RX	Schütz S	Contacto NO S137C/ 12V
1-1618-594936	VS-C137-17,5 Verbindungsschiene		Tie bar
1-1618-599908	C137 C/110EX	Schütz S	Contacto NO S137C3/110V
1-1618-599919	C137 C/ 36EX	Schütz S	Contacto NO S137C3/ 36V
1-1618-599920	C137 C/ 24EX	Schütz S	Contacto NO S137C3/ 24V
1-1618-747378	HK-C137 Hilfskontaktgruppe		Auxiliary contact, set
1-1618-747823	C137 C/ 24EV	Schütz S	Contacto NO S137C1/ 24V
1-1618-747845	C137 C/120EV	Schütz S	Contacto NO S137C1/120V
1-1618-747856	C137 C/ 36EV	Schütz S	Contacto NO S137C1/ 36V
1-1618-825172	C137 B/ 24EV	Schütz S	Contacto NO S137B1/ 24V

C137	Beschreibung	Description	Alter Schlüssel
1-1618-835395	C137 C/ 72ET	Schütz S	Contacto NO S137C1DT/ 72V
1-1618-836296	C137 C/ 60RX 003	Schütz S	Contacto NO S137C/ 60V-WS
1-1618-836956	C137 C/ 96EV	Schütz S	Contacto NO S137C1/ 96V

C163	Beschreibung	Description	Alter Schlüssel
1-1620-100972	C163 C/ 24BX-J1 011	Schütz S	Contacto NO S163 CB/24V-HKG-neg
1-1620-127058	C163 C/ 48EV	Schütz S	Contacto NO S163C1/ 48V
1-1620-134567	C163 C/ 80EV	Schütz S	Contacto NO S163C1/ 80V
1-1620-168651	C163 C/110EV	Schütz S	Contacto NO S163C1/110V
1-1620-184084	C163 F/ 48NX 004	Schütz S	Contacto NO S163F/48V-HK
1-1620-189227	C163 C/120NX	Schütz S	Contacto NO S163C/120V
1-1620-211460	C163 C/ 36EV-R1	Schütz S	Contacto NO S163C1/36V-HK
1-1620-251413	C163 C/110ET	Schütz S	Contacto NO S163C1DT/110V
1-1620-251424	C163 H/110ET	Schütz W	Contacto CO S163H1DT/110V
1-1620-262402	C163 C/ 96EV	Schütz S	Contacto NO S163C1/ 96V
1-1620-262617	C163 C/ 48NX 002	Schütz S	Contacto NO S163C/48V-ST
1-1620-262639	C163 C/ 80NX 002	Schütz S	Contacto NO S163C/80V-ST
1-1620-262640	C163 C/ 24NX 002	Schütz S	Contacto NO S163C/24V-ST
1-1620-263212	C163 H/ 24EV	Schütz W	Contacto CO S163H1/ 24V
1-1620-292970	C163 C/ 60EX	Schütz S	Contacto NO S163C3/ 60V
1-1620-296825	C163 C/ 12EX	Schütz S	Contacto NO S163C3/ 12V
1-1620-296836	C163 C/ 24EX	Schütz S	Contacto NO S163C3/ 24V
1-1620-432383	HK-C163	Hilfskontaktgruppe	Auxiliary contact, set
1-1620-432510	C163 A/ 24RX	Schütz S	Contacto NO S163A/ 24V
1-1620-478981	C163 C/ 24RX	Schütz S	Contacto NO S163C/ 24V
1-1620-479008	C163 C/ 80RX	Schütz S	Contacto NO S163C/ 80V
1-1620-509289	C163 C/ 12RX	Schütz S	Contacto NO S163C/ 12V
1-1620-521347	C163 H/ 24RX	Schütz W	Contacto CO S163H/ 24V
1-1620-521369	C163 G/ 24RX	Schütz W	Contacto CO S163G/ 24V
1-1620-529647	C163 C/ 48RX	Schütz S	Contacto NO S163C/ 48V
1-1620-529658	C163 C/ 36RX	Schütz S	Contacto NO S163C/ 36V
1-1620-530807	C163 H/ 12RX	Schütz W	Contacto CO S163H/ 12V
1-1620-530829	C163 H/ 48RX	Schütz W	Contacto CO S163H/ 48V
1-1620-533066	C163 C/ 72RX	Schütz S	Contacto NO S163C/ 72V
1-1620-537922	C163 C/120EV	Schütz S	Contacto NO S163C1/120V

C163	Beschreibung	Description	Alter Schlüssel
1-1620-537933	C163 C/ 24EV	C163 C/ 24EV	Contactator NO S163C1/ 24V
1-1620-538265	VS-C163-47,0	VS-C163-47,0	Tie bar
1-1620-538276	VS-C163-23,5	VS-C163-23,5	Tie bar
1-1620-538607	C163 C/ 36EV	C163 C/ 36EV	Contactator NO S163C1/ 36V
1-1620-539473	C163 B/ 24EV	C163 B/ 24EV	Contactator NO S163B1/ 24V
1-1620-592463	C163 C/ 48EX	C163 C/ 48EX	Contactator NO S163C3/ 48V
1-1620-745576	C163 H/ 72RX	C163 H/ 72RX	Contactator CO S163H/ 72V
1-1620-786964	C163 C/ 60EV	C163 C/ 60EV	Contactator NO S163C1/ 60V
1-1620-804846	C163 C/ 24ED	C163 C/ 24ED	Contactator NO S163C1D/ 24V
1-1620-805656	C163 C/ 36ET	C163 C/ 36ET	Contactator NO S163C1D18T/36V
1-1620-825343	C163 C/ 24ET	C163 C/ 24ET	Contactator NO S163C1D18T/24V
1-1620-825354	C163 C/110ET	C163 C/110ET	Contactator NO S163C1D51T/110V
1-1620-835408	C163 B/ 48EV-S1	C163 B/ 48EV-S1	Contactator NO S163B1/ 48V-HKG
1-1620-835599	C163 B/ 24EV-S1	C163 B/ 24EV-S1	Contactator NO S163B1/ 24V-HKG
1-1620-835602	C163 C/ 60EV-S1	C163 C/ 60EV-S1	Contactator NO S163C1/ 60V-HKG
1-1620-835691	C163 C/ 12EV	C163 C/ 12EV	Contactator NO S163C1/ 12V
1-1620-835737	C163 C/ 60EV-R1 006	C163 C/ 60EV-R1 006	Contactator NO S163C1/60V-HK-HS
1-1620-836989	C163 C/ 12RX 007	C163 C/ 12RX 007	Contactator NO S163C/12V-SPEZIAL
1-1620-838305	C163 H/110ET	C163 H/110ET	Contactator CO S163H1D51T/110V
1-1620-888742	C163 C/ 60BX-U1	C163 C/ 60BX-U1	Contactator NO S163 CB/60V/HKG
1-1620-923390	C163 H/ 60EV	C163 H/ 60EV	Contactator CO S163H1/ 60V
1-1620-924268	C163 C/ 72EV-R1 008	C163 C/ 72EV-R1 008	Contactator NO S163C1/72V-US-AUX
1-1620-925169	C163 C/ 72EV	C163 C/ 72EV	Contactator NO S163C1/72V

C164	Beschreibung	Description	Alter Schlüssel
1-1622-184119	C164 F/ 48RX 009	Schütz S	Contactator NO S164F/48V-HK
1-1622-221332	C164 C/ 48EV	Schütz S	Contactator NO S164C1/ 48V
1-1622-251435	C164 C/ 36ET	Schütz S	Contactator NO S164C1DT/ 36V
1-1622-251457	C164 C/110ET	Schütz S	Contactator NO S164C1DT/110V
1-1622-262651	C164 C/ 48RX 002	Schütz S	Contactator NO S164C/48V-ST
1-1622-262662	C164 I/ 80RX 002	Schütz W	Contactator CO S164I/80V-ST
1-1622-262673	C164 I/ 48RX 002	Schütz W	Contactator CO S164I/48V-ST
1-1622-262684	C164 I/ 24RX 002	Schütz W	Contactator CO S164I/24V-ST
1-1622-262695	C164 C/ 24RX 002	Schütz S	Contactator NO S164C/24V-ST
1-1622-262706	C164 C/ 80RX 002	Schütz S	Contactator NO S164C/80V-ST
1-1622-292878	C164 C/ 60EX	Schütz S	Contactator NO S164C3/ 60V
1-1622-294589	C164 C/ 48EX	Schütz S	Contactator NO S164C3/ 48V
1-1622-349383	C164 I/ 24RX	Schütz W	Contactator CO S164I/ 24V
1-1622-349394	C164 I/ 48RX	Schütz W	Contactator CO S164I/ 48V
1-1622-349407	C164 I/ 80RX	Schütz W	Contactator CO S164I/ 80V
1-1622-359051	C164 I/ 72RX	Schütz W	Contactator CO S164I/ 72V
1-1622-426300	C164 C/ 24RX	Schütz S	Contactator NO S164C/ 24V
1-1622-426515	VS-C164-56,0	Verbindungsschiene	Tie bar
1-1622-426606	C164 C/ 80RX	Schütz S	Contactator NO S164C/ 80V
1-1622-426684	HK-C164	Hilfskontaktgruppe	Auxiliary contact, set
1-1622-439817	C164 C/ 12RX	Schütz S	Contactator NO S164C/ 12V
1-1622-439839	C164 C/ 48RX	Schütz S	Contactator NO S164C/ 48V
1-1622-469330	C164 C/ 24EV	Schütz S	Contactator NO S164C1/ 24V
1-1622-469341	C164 C/ 72EV	Schütz S	Contactator NO S164C1/ 72V
1-1622-537342	C164 D/ 80RX 010	Schütz S	Contactator NO S164D/80V/60%
1-1622-589616	C164 C/ 80EV	Schütz S	Contactator NO S164C1/ 80V
1-1622-784300	C164 C/ 36EV	Schütz S	Contactator NO S164C1/ 36V
1-1622-825058	C164 C/110EV	Schütz S	Contactator NO S164C1/110V
1-1622-989210	C164 C/ 24ET	Schütz S	Contactator NO S164C1D18T/24V

C165	Beschreibung	Description	Alter Schlüssel
1-1626-10030	C165 C/ 48EV-R1	Schütz S	Contactator NO S165C1/ 48V-HK
1-1626-111531	C165 C/ 60EX	Schütz S	Contactator NO S165C3/60V
1-1626-209810	C165 C/ 48EV	Schütz S	Contactator NO S165C1/ 48V
1-1626-214129	C165 H/ 24EV	Schütz W	Contactator CO S165H1/24V
1-1626-262719	C165 C/ 24RX 002	Schütz S	Contactator NO S165C/24V-ST
1-1626-262720	C165 C/ 48RX 002	Schütz S	Contactator NO S165C/48V-ST
1-1626-262731	C165 C/ 80RX 002	Schütz S	Contactator NO S165C/80V-ST
1-1626-345029	C165 C/ 48EX	Schütz S	Contactator NO S165C3/48V
1-1626-348824	C165 C/ 24EV	Schütz S	Contactator NO S165C1/24V
1-1626-354385	C165 C/ 80EV	Schütz S	Contactator NO S165C1/80V
1-1626-540360	C165 C/ 12RX	Schütz S	Contactator NO S165C/ 12V
1-1626-540382	C165 C/ 24RX	Schütz S	Contactator NO S165C/ 24V
1-1626-540406	C165 C/ 48RX	Schütz S	Contactator NO S165C/ 48V
1-1626-540428	C165 C/ 80RX	Schütz S	Contactator NO S165C/ 80V
1-1626-540508	C165 H/ 12RX	Schütz W	Contactator CO S165H/ 12V
1-1626-540520	C165 H/ 24RX	Schütz W	Contactator CO S165H/ 24V
1-1626-540553	C165 H/ 72RX	Schütz W	Contactator CO S165H/ 72V
1-1626-540973	VS-C165-32,5	Verbindungsschiene	Tie bar
1-1626-542866	HK-C165	Hilfskontaktgruppe	Auxiliary contact, set
1-1626-580266	C165 C/ 36EV	Schütz S	Contactator NO S165C1/36V
1-1626-989298	C165 C/ 24ET	Schütz S	Contactator NO S165C1D18T/24V