

**New order code C152 to C159**

C152 C02-E- 24EV-X11-LV 001

C152: Type

Type of main switching element

No of NO

No of NC

S = Power saving resistor

E = Power saving circuit

X = no power saving equipment

Coil voltage

Tolerance:

E = +25%/-30%

N = +20%/-30%

A = +15%/-15%

C = +16,5%/-10%

D = +10%/-10%

F = +25%/-10%

H = +20%/-10%

S = +15%/-25%

Back voltage suppression:

T = Transzorb Diode

V = Varistor

X = none

Type of auxiliary contact

No of NO

(or CO for snap action switches)

No of NC

(void for snap action switches)

Arc extinction:

L = Arc chamber for S306

M = Arc chamber for S307

N = Arc chamber for S309

O = Arc chamber for S310

P = Extinction chamber for S307 DC

V = with 4 tie bars

W = with 2 tie bars

Special versions

## Schaltelemente

A	S306 A
C	S306 C
D	S307 A
E	S307 E
F	S307 C
G	S307 G
H	S309 G
J	S309 G /S1
K	S306 K
M	S306 M
N	S307 G /N
P	S307 C /N
Q	S307 G /N SN
R	S310 A
S	S310 C

## Hilfskontaktelemente

X	S007 A
Y	S007 C
Z	S005 A

## Schnappschalter (immer Wechsler)

G	S826 a S2
K	S826 a 20 S1
T	S800 a S2

C152	Beschreibung	Description	Alter Schlüssel
I-1644-106244	C152 C20-S-120EX 002	Schutz 2pol.	C152 C20-S-120EX 002 Contactor 2p
I-1644-120886	C152 M20-S-110NV-T2-L	Schutz 2pol.	C152 M20-S-110NV-T2-L Contactor 2p
I-1644-175160	C152 C02-S-58EX-G2	Schutz 2pol.	C152 C02-S-58EX-G2 Contactor 2p
I-1644-200777	C152 A02-S-60NX-G3	Schutz 2pol.	C152 A02-S-60NX-G3 Contactor 2p
I-1644-213659	C152 M20-S-24NX-T1	Schutz 2pol.	C152 M20-S-24NX-T1 Contactor 2p
I-1644-251935	C152 M02-S-80NX-X02	Schutz 2pol.	C152 M02-S-80NX-X02 Contactor 2p
I-1644-262786	C152 A02-S-24NX-X10 003	Schutz 2pol.	C152 A02-S-24NX-X10 003 Contactor 2p
I-1644-273673	C152 M11-S-24NX 001	Schutz 2pol.	C152 M11-S-24NX 001 Contactor 2p
I-1644-273913	C152 M02-S-110NX-X11	Schutz 2pol.	C152 M02-S-110NX-X11 Contactor 2p
I-1644-273957	C152 M20-S-110NX-T2	Schutz 2pol.	C152 M20-S-110NX-T2 Contactor 2p
I-1644-274198	C152 C02-S-48NX-X11	Schutz 2pol.	C152 C02-S-48NX-X11 Contactor 2p
I-1644-274245	C152 C02-S-110NX-X01	Schutz 2pol.	C152 C02-S-110NX-X01 Contactor 2p
I-1644-274336	C152 M20-S-250NX 002	Schutz 2pol.	C152 M20-S-250NX 002 Contactor 2p
I-1644-274472	C152 M20-S-60NX-T3 002	Schutz 2pol.	C152 M20-S-60NX-T3 002 Contactor 2p
I-1644-294590	C152 C20-S-110NX-X10	Schutz 2pol.	C152 C20-S-110NX-X10 Contactor 2p
I-1644-331928	C152 C02-S-24NX-X20 002	Schutz 2pol.	C152 C02-S-24NX-X20 002 Contactor 2p
I-1644-347150	C152 M02-S-200NX-X11	Schutz 2pol.	C152 M02-S-200NX-X11 Contactor 2p
I-1644-348722	C152 C20-S-24NX 002	Schutz 2pol.	C152 C20-S-24NX 002 Contactor 2p
I-1644-354396	C152 M20-S-60NX-X20	Schutz 2pol.	C152 M20-S-60NX-X20 Contactor 2p
I-1644-371868	C152 M20-S-110NX-Y12 002	Schutz 2pol.	C152 M20-S-110NX-Y12 002 Contactor 2p
I-1644-413713	C152 C20-S-48NX-X22	Schutz 2pol.	C152 C20-S-48NX-X22 Contactor 2p
I-1644-502391	C152 C11-S-24EV	Schutz 2pol.	C152 C11-S-24EV Contactor 2p
I-1644-527414	C152 M20-S-60NV-X11	Schutz 2pol.	C152 M20-S-60NV-X11 Contactor 2p
I-1644-528462	C152 C02-S-62SX-G2	Schutz 2pol.	C152 C02-S-62SX-G2 Contactor 2p
I-1644-529692	C152 M20-S-250NX-X10	Schutz 2pol.	C152 M20-S-250NX-X10 Contactor 2p
I-1644-573768	C152 M20-S-60NX-X30	Schutz 2pol.	C152 M20-S-60NX-X30 Contactor 2p
I-1644-599828	C152 M20-S-200NX-X11	Schutz 2pol.	C152 M20-S-200NX-X11 Contactor 2p
I-1644-744777	C152 M11-S-220NX	Schutz 2pol.	C152 M11-S-220NX Contactor 2p
I-1644-835828	C152 K02-S-24EV-G2 004	Schutz 2pol.	C152KE-02-S-24-G2
I-1644-836809	C152 K20-S-110EV-G1-L 008	Schutz 2pol.	S152KE-20-S-110-X20E-G1-LBK
I-1644-989356	C152 A20-S-110EX-G3-L	Schutz 2pol.	S152AE-20-S-110-G3-LBK

<b>C153</b>	<b>Beschreibung</b>		<b>Description</b>	<b>Alter Schlüssel</b>
I-1645-105161	C153 A30-S-120NX-G2 006	Schutz 3pol.	C153 A30-S-120NX-G2 006	S153 a/2d - H3S - St2W - 120V
I-1645-105172	C153 A30-S-220EX-G2 006	Schutz 3pol.	C153 A30-S-220EX-G2 006	S153 a/2d - H3S - St2W - 220V
I-1645-162415	C153 A03-S- 58NX-K1	Schutz 3pol.	C153 A03-S- 58NX-K1	S153 a/1f - H3Ö - St1W - 58V
I-1645-235433	C153 M21-S- 24NX-G1 004	Schutz 3pol.	C153 M21-S- 24NX-G1 004	S153 m/1d - H1Ö/2S - St1W - 24V
I-1645-274701	C153 M21-S- 24NX 001	Schutz 3pol.	C153 M21-S- 24NX 001	S153 m/- - H1Ö/2S - 24V
I-1645-274712	C153 M21-S- 40NX-X01 005	Schutz 3pol.	C153 M21-S- 40NX-X01 005	S153 m/1x - H1Ö/2S - St1Ö - 40V
I-1645-274734	C153 M21-S- 24NX-X01	Schutz 3pol.	C153 M21-S- 24NX-X01	S153 m/1x - H1Ö/2S - St1Ö - 24V
I-1645-274825	C153 C21-S- 40NX	Schutz 3pol.	C153 C21-S- 40NX	S153 c/- H1Ö/2S - 40V
I-1645-274950	C153 A03-S-200NX-T3	Schutz 3pol.	C153 A03-S-200NX-T3	S153 a/3t - H3Ö - St3W - 200V
I-1645-292958	C153 C30-S- 48NV-G2	Schutz 3pol.	C153 C30-S- 48NV-G2	S153 c/2d - H3S - St2W - 48V
I-1645-431722	C153 K03-S-180NX-X11	Schutz 3pol.	C153 K03-S-180NX-X11	S153 k/2x - H3Ö - St1Ö/1W - 180V
I-1645-520093	C153 C12-S- 40NX	Schutz 3pol.	C153 C12-S- 40NX	S153 c/- H2Ö/1S - 40V
I-1645-565461	C153 K30-S- 96NX	Schutz 3pol.	C153 K30-S- 96NX	S153 k/- - H3S - 96V
I-1645-784537	C153 K30-S-110EV-G2 007	Schutz 3pol.	C153 K30-S-110EV-G2 007	S153 k/2d - H3S - St2W - 110V
I-1645-835748	C153 K03-S- 24NX-K2	Schutz 3pol.	C153 K03-S- 24NX-K2	S153 k/2f - H3Ö - St2W - 24V
I-1645-988751	C153 A30-S- 26EV-G2	Schutz 3pol.	C153 A30-S- 26EV-G2	S153AE-30-S-26-G2
I-1645-989209	C153 C30-S- 96EX-T2	Schutz 3pol.	C153 C30-S- 96EX-T2	S153 c/2t - H3S - St2W - 96V
<b>C154</b>	<b>Beschreibung</b>		<b>Description</b>	<b>Alter Schlüssel</b>
I-1646-185394	C154 K22-S-340NX	Schutz 4pol.	C154 K22-S-340NX	S154 k/- H2Ö/2S - 340V
I-1646-275420	C154 M22-S- 60NX-T3 002	Schutz 4pol.	C154 M22-S- 60NX-T3 002	S154 m/3t - H2Ö/2S - St3W - 60V
I-1646-334632	C154 C22-S- 24NX-Z10	Schutz 4pol.	C154 C22-S- 24NX-Z10	S154 c/1z - H2Ö/2S - St1S - 24V
I-1646-349747	C154 C40-S-220DX-X30	Schutz 4pol.	C154 C40-S-220DX-X30	S154 c/3x - H4S - St3S - 220V
I-1646-354409	C154 M04-S- 60DX-X21	Schutz 4pol.	C154 M04-S- 60DX-X21	S154 m/3x - H4Ö - St1Ö/2S - 60V
I-1646-567343	C154 A40-S-200DX-T1	Schutz 4pol.	C154 A40-S-200DX-T1	S154 a/1t - H4S - St1W - 200V
I-1646-573780	C154 M04-S- 60DX-X30	Schutz 4pol.	C154 M04-S- 60DX-X30	S154 m/3x - H4Ö - St3S - 60V
I-1646-573804	C154 M40-S- 60DX-X30	Schutz 4pol.	C154 M40-S- 60DX-X30	S154 m/3x - H4S - St3S - 60V
I-1646-835839	C154 K04-S- 24EV-G2 004	Schutz 4pol.	C154 K04-S- 24EV-G2 004	S154KE-04-S-24-G2



<b>C156</b>	<b>Beschreibung</b>	<b>Schütz</b>	<b>3pol.</b>	<b>Description</b>	<b>Alter Schlüssel</b>
I-1648-101759	C156 E30-S- 30EV-G2-N	Schütz	3pol.	C156 E30-S- 30EV-G2-N	Contactor 3p
I-1648-150309	C156 E03-S- 24NX-X10	Schütz	3pol.	C156 E03-S- 24NX-X10	Contactor 3p
I-1648-181347	C156 E30-S- 60NX-T3	Schütz	3pol.	C156 E30-S- 60NX-T3	Contactor 3p
I-1648-189023	C156 E03-S- 48NX-G1	Schütz	3pol.	C156 E03-S- 48NX-G1	Contactor 3p
I-1648-276252	C156 E03-S- 60NX-T3	Schütz	3pol.	C156 E03-S- 60NX-T3	Contactor 3p
I-1648-319713	C156 G30-S- 24NX 002	Schütz	3pol.	C156 G30-S- 24NX 002	Contactor 3p
I-1648-322399	C156 E30-S- 24NX-X21	Schütz	3pol.	C156 E30-S- 24NX-X21	Contactor 3p
I-1648-451179	C156 xxx-S- 60SX-G2 017	Schütz	3pol.	C156 xxx-S- 60SX-G2 017	Contactor 3p
I-1648-582660	C156 E30-S- 24NX-X21 016	Schütz	3pol.	C156 E30-S- 24NX-X21 016	Contactor 3p
I-1648-587701	C156 J03-S- 62SX-G2 017	Schütz	3pol.	C156 J03-S- 62SX-G2 017	Contactor 3p
I-1648-598927	C156 xxx-S- 60SX-K2 017	Schütz	3pol.	C156 xxx-S- 60SX-K2 017	Contactor 3p
I-1648-784242	C156 D03-S-110HX-X11	Schütz	3pol.	C156 D03-S-110HX-X11	Contactor 3p
I-1648-787412	C156 G30-S- 60NX-T1	Schütz	3pol.	C156 G30-S- 60NX-T1	Contactor 3p
I-1648-787865	C156 F30-E- 24EX-G1	Schütz	3pol.	C156 F30-E- 24EX-G1	Contactor 3p
I-1648-800004	C156 G30-S- 48NX-T1	Schütz	3pol.	C156 G30-S- 48NX-T1	Contactor 3p
I-1648-804471	C156 G30-S- 96CX-X21 011	Schütz	3pol.	C156 G30-S- 96CX-X21 011	Contactor 3p
I-1648-804857	C156 G30-S- 24EV-G1	Schütz	3pol.	C156 G30-S- 24EV-G1	Contactor 3p
I-1648-824920	C156 G30-S- 24FV-X10-N 002	Schütz	3pol.	C156 G30-S- 24EV-X10-N 002	Contactor 3p
I-1648-824931	C156 G03-S- 24FV-X10-N	Schütz	3pol.	C156 G03-S- 24FV-X10-N	Contactor 3p
I-1648-8335806	C156 N21-S- 24EV-G2-P 004	Schütz	3pol.	C156 N21-S- 24EV-G2-P 004	Contactor 3p
I-1648-8335851	C156 F20-E- 24EX-G2 023	Schütz	3pol.	C156 F20-E- 24EX-G2 023	Contactor 3p
I-1648-868759	C156 E30-S-110ET-G1-W 004	Schütz	3pol.	C156 E30-S-110ET-G1-W 004	Contactor 3p
I-1648-887636	C156 E30-S-110EV-G3-N 022	Schütz	3pol.	C156 E30-S-110EV-G3-N 022	Contactor 3p
I-1648-987974	C156 E03-S-220NX-G1	Schütz	3pol.	C156 E03-S-220NX-G1	Contactor 3p
I-1648-988682	C156 E30-S- 36NX-G2	Schütz	3pol.	C156 E30-S- 36NX-G2	Contactor 3p
I-1648-988693	C156 E03-S- 36NX-G2	Schütz	3pol.	C156 E03-S- 36NX-G2	Contactor 3p
I-1648-989038	C156 E30-S-110EV-G2-N	Schütz	3pol.	C156 E30-S-110EV-G2-N	Contactor 3p
				S156 e/3x - H3S - St10/2S - 24V	
				S156/S309G/S1/2D-62V	
				S156 a/2x - H30 - St10/1S - 110V	
				S156 g/1t - H3S - St1W - 60V	
				S156CE-30-E-24-G1	
				S156 g/1t - H3S - St1W - 48V	
				S156 g/3x - H3S - St10/2S - 96V	
				S156GE-30-S-24-G1	
				S156 g/1x - H3S - St1S - 24V - LBK	
				S156 g/1x - H30 - St1S - 24V - LBK	
				S156-N21-S-24-G2	
				S156CE-30-E-24-G2-X02	
				S156 e/1d - H3S - St1W - 110V	
				S156EE-30-S-110-G3-LBK	
				S156 e/1d - H30 - St1W - 220V	
				S156 e/2d - H3S - St2W - 36V	
				S156 e/2d - H30 - St2W - 36V	
				S156EE-30-S-110-G2	

C157	Beschreibung		Description	Alter Schlüssel
I-1649-112443	C157 G22-S- 24NV-X11	Schütz 4pol.	C157 G22-S- 24NV-X11	Contacto 4p
I-1649-171419	C157 G40-S- 24DX-X30 002	Schütz 4pol.	C157 G40-S- 24DX-X30 002	Contacto 4p
I-1649-189567	C157 J40-S-220DX-G2	Schütz 4pol.	C157 J40-S-220DX-G2	Contacto 4p
I-1649-190590	C157 G02-S- 60NX	Schütz 4pol.	C157 G02-S- 60NX	Contacto 4p
I-1649-251833	C157 G40-S- 24DV-T3	Schütz 4pol.	C157 G40-S- 24DV-T3	Contacto 4p
I-1649-251902	C157 H40-S- 24DX-X30	Schütz 4pol.	C157 H40-S- 24DX-X30	Contacto 4p
I-1649-294512	C157 G40-X- 64EX-N 012	Schütz 4pol.	C157 G40-X- 64EX-N 012	Contacto 4p
I-1649-296881	C157 E40-S- 48DX-K1	Schütz 4pol.	C157 E40-S- 48DX-K1	Contacto 4p
I-1649-395295	C157 G40-S-220DX	Schütz 4pol.	C157 G40-S-220DX	Contacto 4p
I-1649-507205	C157 G04-S- 62AX-G2	Schütz 4pol.	C157 G04-S- 62AX-G2	Contacto 4p
I-1649-509701	C157 G40-S-180DX-G2	Schütz 4pol.	C157 G40-S-180DX-G2	Contacto 4p
I-1649-542435	C157 G40-S-220DX-X10	Schütz 4pol.	C157 G40-S-220DX-X10	Contacto 4p
I-1649-548104	C157 E04-S- 60SX-K3 020	Schütz 4pol.	C157 E04-S- 60SX-K3 020	Contacto 4p
I-1649-561469	C157 H40-S- 96DX-G1	Schütz 4pol.	C157 H40-S- 96DX-G1	Contacto 4p
I-1649-566646	C157 G40-S- 24DX	Schütz 4pol.	C157 G40-S- 24DX	Contacto 4p
I-1649-572685	C157 G40-S- 96DX-T3	Schütz 4pol.	C157 G40-S- 96DX-T3	Contacto 4p
I-1649-574658	C157 H40-S-220DX-X21	Schütz 4pol.	C157 H40-S-220DX-X21	Contacto 4p
I-1649-578047	C157 J04-S- 62DX-G2	Schütz 4pol.	C157 J04-S- 62DX-G2	Contacto 4p
I-1649-584677	C157 J40-S-180DX-G2	Schütz 4pol.	C157 J40-S-180DX-G2	Contacto 4p
I-1649-783976	C157 D40-E-110EX-G1 018	Schütz 4pol.	C157 D40-E-110EX-G1 018	Contacto 4p
I-1649-783998	C157 N40-E-110EX-G1-PV 019	Schütz 4pol.	C157 N40-E-110EX-G1-PV 019	Contacto 4p
I-1649-784684	C157 F22-S- 24NX	Schütz 4pol.	C157 F22-S- 24NX	Contacto 4p
I-1649-787127	C157 F40-E- 60EX-G1	Schütz 4pol.	C157 F40-E- 60EX-G1	Contacto 4p
I-1649-787172	C157 G40-X- 80 X-X22 011	Schütz 4pol.	C157 G40-X- 80 X-X22 011	Contacto 4p
I-1649-787821	C157 E40-E-100EX-G2-NV	Schütz 4pol.	C157 E40-E-100EX-G2-NV	Contacto 4p
I-1649-824884	C157 N40-E- 24EX-G1-P	Schütz 4pol.	C157 N40-E- 24EX-G1-P	Contacto 4p
I-1649-824919	C157 G22-S-200EV-K2	Schütz 4pol.	C157 G22-S-200EV-K2	Contacto 4p
I-1649-825730	C157 N40-S- 24EV-K1-PV	Schütz 4pol.	C157 N40-S- 24EV-K1-PV	Contacto 4p
I-1649-836694	C157 N40-S-110EV-K1-PV 002	Schütz 4pol.	C157 N40-S-110EV-K1-PV 002	Contacto 4p
I-1649-836763	C157 E22-S-110EV-G1-NV	Schütz 4pol.	C157 E22-S-110EV-G1-NV	Contacto 4p
I-1649-836990	C157 G40-S- 24EV-G1	Schütz 4pol.	C157 G40-S- 24EV-G1	Contacto 4p
I-1649-868839	C157 D22-S- 24NX-T1	Schütz 4pol.	C157 D22-S- 24NX-T1	Contacto 4p
I-1649-888413	C157 E40-E- 24EX-G1	Schütz 4pol.	C157 E40-E- 24EX-G1	Contacto 4p
I-1649-924439	C157 E04-S- 24HV-K3	Schütz 4pol.	C157 E04-S- 24HV-K3	Contacto 4p
I-1649-988740	C157 N22-S- 26EV-G3-P 021	Schütz 4pol.	C157 N22-S- 26EV-G3-P 021	Contacto 4p
I-1649-989016	C157 G40-S-220HV-X30-NV 002	Schütz 4pol.	C157 G40-S-220HV-X30-NV 002	Contacto 4p
I-1649-112443	C157 G22-S- 24NV-X11	Schütz 4pol.	C157 G22-S- 24NV-X11	Contacto 4p
I-1649-171419	C157 G40-S- 24DX-X30 002	Schütz 4pol.	C157 G40-S- 24DX-X30 002	Contacto 4p
I-1649-189567	C157 J40-S-220DX-G2	Schütz 4pol.	C157 J40-S-220DX-G2	Contacto 4p
I-1649-190590	C157 G02-S- 60NX	Schütz 4pol.	C157 G02-S- 60NX	Contacto 4p
I-1649-251833	C157 G40-S- 24DV-T3	Schütz 4pol.	C157 G40-S- 24DV-T3	Contacto 4p
I-1649-251902	C157 H40-S- 24DX-X30	Schütz 4pol.	C157 H40-S- 24DX-X30	Contacto 4p
I-1649-294512	C157 G40-X- 64EX-N 012	Schütz 4pol.	C157 G40-X- 64EX-N 012	Contacto 4p
I-1649-296881	C157 E40-S- 48DX-K1	Schütz 4pol.	C157 E40-S- 48DX-K1	Contacto 4p
I-1649-395295	C157 G40-S-220DX	Schütz 4pol.	C157 G40-S-220DX	Contacto 4p
I-1649-507205	C157 G04-S- 62AX-G2	Schütz 4pol.	C157 G04-S- 62AX-G2	Contacto 4p
I-1649-509701	C157 G40-S-180DX-G2	Schütz 4pol.	C157 G40-S-180DX-G2	Contacto 4p
I-1649-542435	C157 G40-S-220DX-X10	Schütz 4pol.	C157 G40-S-220DX-X10	Contacto 4p
I-1649-548104	C157 E04-S- 60SX-K3 020	Schütz 4pol.	C157 E04-S- 60SX-K3 020	Contacto 4p
I-1649-561469	C157 H40-S- 96DX-G1	Schütz 4pol.	C157 H40-S- 96DX-G1	Contacto 4p
I-1649-566646	C157 G40-S- 24DX	Schütz 4pol.	C157 G40-S- 24DX	Contacto 4p
I-1649-572685	C157 G40-S- 96DX-T3	Schütz 4pol.	C157 G40-S- 96DX-T3	Contacto 4p
I-1649-574658	C157 H40-S-220DX-X21	Schütz 4pol.	C157 H40-S-220DX-X21	Contacto 4p
I-1649-578047	C157 J04-S- 62DX-G2	Schütz 4pol.	C157 J04-S- 62DX-G2	Contacto 4p
I-1649-584677	C157 J40-S-180DX-G2	Schütz 4pol.	C157 J40-S-180DX-G2	Contacto 4p
I-1649-783976	C157 D40-E-110EX-G1 018	Schütz 4pol.	C157 D40-E-110EX-G1 018	Contacto 4p
I-1649-783998	C157 N40-E-110EX-G1-PV 019	Schütz 4pol.	C157 N40-E-110EX-G1-PV 019	Contacto 4p
I-1649-784684	C157 F22-S- 24NX	Schütz 4pol.	C157 F22-S- 24NX	Contacto 4p
I-1649-787127	C157 F40-E- 60EX-G1	Schütz 4pol.	C157 F40-E- 60EX-G1	Contacto 4p
I-1649-787172	C157 G40-X- 80 X-X22 011	Schütz 4pol.	C157 G40-X- 80 X-X22 011	Contacto 4p
I-1649-787821	C157 E40-E-100EX-G2-NV	Schütz 4pol.	C157 E40-E-100EX-G2-NV	Contacto 4p
I-1649-824884	C157 N40-E- 24EX-G1-P	Schütz 4pol.	C157 N40-E- 24EX-G1-P	Contacto 4p
I-1649-824919	C157 G22-S-200EV-K2	Schütz 4pol.	C157 G22-S-200EV-K2	Contacto 4p
I-1649-825730	C157 N40-S- 24EV-K1-PV	Schütz 4pol.	C157 N40-S- 24EV-K1-PV	Contacto 4p
I-1649-836694	C157 N40-S-110EV-K1-PV 002	Schütz 4pol.	C157 N40-S-110EV-K1-PV 002	Contacto 4p
I-1649-836763	C157 E22-S-110EV-G1-NV	Schütz 4pol.	C157 E22-S-110EV-G1-NV	Contacto 4p
I-1649-836990	C157 G40-S- 24EV-G1	Schütz 4pol.	C157 G40-S- 24EV-G1	Contacto 4p
I-1649-868839	C157 D22-S- 24NX-T1	Schütz 4pol.	C157 D22-S- 24NX-T1	Contacto 4p
I-1649-888413	C157 E40-E- 24EX-G1	Schütz 4pol.	C157 E40-E- 24EX-G1	Contacto 4p
I-1649-924439	C157 E04-S- 24HV-K3	Schütz 4pol.	C157 E04-S- 24HV-K3	Contacto 4p
I-1649-988740	C157 N22-S- 26EV-G3-P 021	Schütz 4pol.	C157 N22-S- 26EV-G3-P 021	Contacto 4p
I-1649-989016	C157 G40-S-220HV-X30-NV 002	Schütz 4pol.	C157 G40-S-220HV-X30-NV 002	Contacto 4p

