SICK

ICS 100

Intelligent Camera Sensor






- Independent, compact unit
- **■** Fast system architecture
- **■** Simple integration
- Intensive and homogenous illumination
- Wide-ranging application field
- Presence monitoring
- Shape, position and dimension check
- Object detection
- Completeness check


to be used within the field of

- Process control
- Quality assurance





- 1 Lens
- 2 Ring light, 15x LED/green lens combination
- 3 Mounting hole M 5, 4-times
- User output, 8-pin, M 12
- 5 Operating unit connection, 5-pin, M 12
- 6 Display of output switching state
- 7 LC Display
- 8 Keyboard
- 9 VSC 100: $WxHxD = 150x82x31 \text{ mm}^3$





ICS 100 Intelligent Camera Sensor

Technical data		ICS 100 VSC 100 -B1111
Scanning distance ¹⁾	70 mm	
Field of view	20 mm x 20 mm	
Teach/search window	2 mm x 2 mm 20 mm x 20 mm,	
	adjustable	
Image sensor	CMOS, 512 x 512 pixel	
Light source ²⁾	15x LED green/Lens combination	
Flash length	30 μs to 1 ms, normally 500 μs	
Number of objects	Up to 16	
Supply voltage U _s ³⁾	24 V DC	
Ripple ⁴⁾	< 5 V _{PP}	
Current consumption ⁵⁾	< 450 mA	
Switching outputs	4 x B (NPN/PNP)	
Output current I _A max. ⁶⁾	< 100 mA	
Response time ⁷⁾ , cycle time ⁷⁾	≥ 2.5 ms	
Switching frequency max. ⁸⁾ 200/s		
Trigger input ⁹⁾ Falling edge, HIGH = 10 V U_S		
Trigger output for ext. lighting 5 V when sender OFF (TTL)		
Connection type setup unit ¹⁰⁾ Connectors 5-pin, M 12		
Connection type user output Plug 8-pin, M 12		
Operating unit display	16 gray levels	
Protection type	IP 64	
	IP 40	
Ambient temperature	Operation 0 °C + 50 °C	
	Storage – 25 °C + 70 °C	
	Storage – 20 °C + 60 °C	
Shock load 15 g, 6 directions		
Weight	Approx. 350 g	
	Approx. 240 g	
Housing material	Aluminium	
	Plastic	

Range depending on object and parameters; e.g.: ± 8 mm with shape check and threshold = 95%Average service life at room

temperature 50,000 h at $T_U = +25$ °C

Limit values ± 20 % Must be within U_S tolerances

Without load

6) Amount total for all four outputs

7) With resistive load

8) With light/dark ratio 1:1 ⁹⁾ 1000 ms > trigger pulse ≥ 2.5 ms;

trigger active when HIGH \geq 1000 ms ¹⁰⁾ Cable length 2 m, PVC, Ø 5 mm, do not distort cable below 0 °C

Ordering information			
Туре		Part no.	
ICS 100-B1111		1 022 631	
VSC 100		2 022 605	
Mounting bracket		4 035 008	
Rod mount. clamp		2 022 464	

Check Mode	Procedure 1)	Typical Applications	
Shape check (pattern matching)	Structures are compared translation- invariant with respect to shape	Shape, position and dimension check, object detection, presence monitoring, completeness	
Multi-area-evaluation	Blobs are compared with respect to number and area	Presence monitoring, completeness monitoring Presence monitoring, e.g., for transparent bodies with reflecting surfaces, completeness monitoring, especially with gloss ²⁾	
Minimum pixel sum	Checking for pixel number exceeding a limit		
Pixel sum	Comparison of the absolute number of white and black dots	Presence monitoring, completeness check	
1) All procedures are used in the binary	2) Made possible by the special		

A comparison is made each time between the taught-in reference image and the image to be checked.

resistance of the sensor against overshooting

•	Shape of tought-in reference image		
5	Rectangular	Shape of reference image = rectangle	
0	Autoshape	Shape of reference image = shape of object in reference image	
) n		(only possible for closed areas)	

Great Britain

Erwin Sick Ltd. Waldkirch House 39 Hedley Road, St. Albans Hertfordshire AL 1 5BN

+44 17 27-83 11 21 Fax +44 17 27-85 67 67 erwin@sick.co.uk

SICK, Inc.

6900 West 110th Street Bloomington, MN 55438

+1 (952) 9 41-67 80 +1 (952) 9 41-92 87 WATS: 1-800-325-7425 info@sickoptic.com

Australia

Erwin Sick Optic-Electronic Pty. Ltd. Head Office, P.O. Box 214 899 Heidelberg Road Ivanhoe, Vic. 3079, Australia

+61 39 49 74 10 0 (0 08) 33 48 02 - toll free +61 39 49 71 18 7

sick@werple.net.au

